



www.bedrockboulders.com info@bedrockboulders.com
Phone 619 442-0574 Fax 619 442-0448

Product Specifications

BEDROCK FIRE PIT INSTALLATION INSTRUCTIONS

Step 1. If it is not going on an existing cement, pavers or flagstone surface then need to level the area where you are placing the fire pit.

Step 2. Start with the bottom row making sure to keep the joints tight, level and even. The first row is the most important. If one block is uneven it will continue up each row making an exaggerated hump at the top.

Step 3. If you are permanently installing your fire pit, place three 2" thick round spots of SRW adhesive on each block of each row.



Step 4. Start the second row by staggering the block to cover half of each block under it. This offset will give it strength and looks pleasing.



Step 5. It maybe necessary to push each block in towards the middle in order to keep the joints tight.



www.bedrockboulders.com info@bedrockboulders.com
Phone 619 442-0574 Fax 619 442-0448

Product Specifications

BEDROCK FIRE PIT INSTALLATION INSTRUCTIONS

Step 6. Continue placing block on each row in the same manor as in steps 4 & 5. Remember to keep all joints Tight as you complete each row.



Step 7. Set the final block in place and you are ready to start your fire.



Remember to always use good common sense when enjoying a fire with your new **BEDROCK FIRE PIT**

